

WILDEY F.A., Inc.
45 ANGEVINE ROAD WARREN, CT. 06754
860-355-9000 www.wildeyguns.com

READ YOUR INSTRUCTION MANUAL BEFORE USING YOUR
NEW PISTOL.

OPERATION NOTES FOR THE WILDEY PISTOL

Load the gun from a closed slide. Put the cam lever down and finger off the trigger. Put a loaded magazine in the gun and manually pull the slide fully back and release. This will load the first round. If the slide doesn't lock closed (at times with reloads) use the heel of your hand to close and lock the action. You are now ready to shoot.

The .475 works best with 5 rounds in the magazine. The other calibers with 6 rounds. After the gun is broken in you may find the .475 O.K with 6 and the others with 7 but this is not an iron clad rule.

The last round, after firing, may not eject. It will drop out when the clip is removed so knowing this it shouldn't be a problem. (Many guns after broken in can be adjusted by backing off the regulator one notch).

For proper operation reloaded (and new) cartridges should have an overall length of 1.580" \pm .010. Long cartridges don't work properly in the magazine and therefore affect the semi-automatic operation, feeding, etc.

For accuracy from the bench **DO NOT REST THE BARREL ON A SANDBAG**. This affects the harmonics of the barrel and causes poor accuracy.

The WILDEY pistol is unique! It is gas operated and works differently from typical blow back type auto loaders. Once you're familiar with the WILDEY we are sure you'll enjoy shooting it and the power it provides.

09/04